

Solar Inverter Wi-Fi Connection Instructions



1. Press WPS button on router
(Your router will start looking for devices for around a minute).



2. Press WPS Button on your TP-Link Wi-Fi Extender.
Your Wi-Fi Extender is plugged into a power outlet by your inverter.

*Wi-Fi extender can also be on the inside wall opposite to your inverter.



3. A green or blue LED light will start blinking as the Wi-Fi Extender searches for your router.

Once the two devices start communicating the light will stay on.

*If your Wi-Fi extender is too far from router, you may bring it to a plug closer to your inverter. Complete the process and then take it back to the original location once communication was achieved.

Questions? Give us a call.
(915) 400-2995